

PRACTICAL REPORT

For IoT Practical



JANUARY 1, 2022

DARSHAN RAMJIYANI (DSP)

DOCS, KSKV Kachchh University

♣ 4.6 Serial Communication – Sending binary data from Arduino.

```
Arduino Code:
int intValue;
int baudRate = 9600;
void setup()
{
       pinMode(LEDPin, OUTPUT);
       /* Established Serial Communication. */
       Serial.begin(baudRate);
       Serial.println("Connection Establishing connection...!");
       while(!Serial){}
       Serial.println("Connection Established!");
       /* Wait until Serial Communication not established. */
       while(!Serial){}
       /* Send data through Serial Communication. */
       Serial.println("- Name of Author: DSP -");
       Serial.println("-----");
}
void loop()
        Serial.print('H');
        intValue = random(599);
        Serial.write(lowByte(intValue));
        Serial.write(highByte(intValue));
        intValue = random(599);
        Serial.write(lowByte(intValue));
        Serial.write(highByte(intValue));
        delay(1000);
}
```

4 4.7 Serial Communication − Receiving binary data from Arduino

Here, we receive data in python program which we have send in 4.6. Requires PySerial library.

Python Code:

```
import serial

connection = serial.Serial("COM7", 9600)

while True:
    Data : str = connection.read()
    Data = int.from_bytes(bytes(connection.read()), "little")
    print("Recieved Data : ", Data)
    Data += int.from_bytes(bytes(connection.read()), "big")
    print("Recieved Data : ", Data)
```

Output:

```
Command Prompt
                                                                                                       Recieved Data : 67
Recieved Data :
               115
Recieved Data :
               231
                                        OUTPUT FROM
               98
Recieved Data :
Recieved Data :
               206
                                     DWAIDH TERMINAL
Recieved Data :
               115
Recieved Data :
               219
Recieved Data :
               100
Recieved Data :
               133
Recieved Data :
               10
Recieved Data :
Recieved Data :
Recieved Data
Recieved Data
Recieved Data :
               133
Recieved Data :
               102
Recieved Data :
               134
Recieved Data :
               117
Recieved Data :
               233
Recieved Data :
               111
ecieved Data
```